


Featured Product . . . EnerMatic System



Ways to communicate with an EnerMatic Controller include GSM cell phones and/or via an Ample Power web server running a custom program. The optional GSM modem permits text message

commands to be received from authorized phone numbers and the EnerMatic Controller will send text messages or email if selected abnormal operating conditions occur.